FEED and PAUSE Self Test

Performing this self test temporarily resets the printer configuration to the factory default values. These values are active only until power is turned off unless you save them permanently in memory. If the factory default values are permanently saved, a media calibration procedure must be performed, and you must reset the head resistance value and the verifier and applicator port settings to their required values.

To perform a FEED and PAUSE self test, complete these steps:

1. Turn Off (**O**) the printer.
2. Press and hold FEED and PAUSE while turning the power On (**I**).
3. Hold FEED and PAUSE until the first control panel light turns off.

   The printer configuration is temporarily reset to the factory default values. No labels print at the end of this test.